AR-600 REMACHADORA

<PART NO. / NAME>		
1-A	Nose piece 2.4mm	
1-B	Nose piece 3.2mm	
1-C	Nose piece 4.0mm	
1-D	Nose piece 4.8mm	
1-A	Nose piece 4.0mm	
1-B	Nose piece 4.8mm	
1-C	Nose piece 6.4mm	
5	Jaw case	
7	Jaw	
8	Jaw pusher	
9	Jaw pusher spring	
10	Jaw case lock nut	
12	Booster	
13	Booster head	
14	Return cap	
15	Hanger	
16	Dust cap	
17	O-ring P-12	
19	B-ring P-12	
21	Booster piston	
23	O-ring P-22	
24	B-ring P-22	
25	Returning spring (S)	
	Returning spring (L)	
26	Cylinder tube	
27	O-ring G-70	
28	Cylinder cap	
29	Booster lock nut	
30	O-ring P-12	
32	B-ring P-12	
34	Cushion rubber	
35	Trigger A	
36	Trigger B	
37	Connecting lod	
38	Roll pin A	
39	Roll pin B	
40	Roll pin C	
41	Roll pin D	
42	Roll pin E	
43	Spool	
44	Spool spring	
45	O-ring P-3	
46	B-ring P-5	
48	Ball valve	
49	Valve spring	
50	Air hose joint 1/4"	
51	Air piston	
52	Piston lod	
53	Air piston lock nut	
54	O-ring P-60	
55	Box nut 1/4"	
56	Air hose joint 1/4"